

Joining a Wifi Network!

You will always have direct access to your Handibot via wireless Access Point (AP) Mode from your PC, tablet, or smart-phone.

But for some operations, it will be more convenient to be on a Wi-Fi network (LAN). There are **2 things you will need** to do first to get onto the network.

- 1. You will need to **know** the *name* of your Wi-Fi network and the *passphrase* to log onto it.
- You will want to have determined a method to identify the IP address for your Handibot once it's on the network.

The easiest method for identifying the IP address of your Handibot on the network is with one of the FabMo Tool Minders.



Also, you can use *general network tools* such as WnetWatcher (Windows) or Fing (Android) to identify your tool and get its IP address.


Another method is to use the administrative tools of your network router for this purpose.

When using these tools, if the Handibot name (FabMo-xxxxx) itself does not appear in the network information listing, the tool may appear as a "Murata Manufacturing" type of unit or as an "Edison" and you can retrieve its associated IP address.

Whatever method you decide to use to identify your Handibot – start the process of getting onto the network from first being in <u>Access Point Mode</u>. {*We'll step through that process again in case your tool is not already there ...}

4 START-UP in AP MODE:

Reminder => Open the WiFi or network manager on the computer or device* that you



Log into your Handibot's Access Point Mode link as you would to a network.

Use the password: go2fabmo

After your device's network manager connects to your Handibot it will say something like: Unidentified network, No Internet Acess".



BUT **you now have a direct link** right into your Handibot – it's called <u>Access Point Mode</u>


This is the linkage that we will use to set-up and test your tool. Your tool will be always available to you in Access Point (AP) Mode (good for job sites, etc...). You also put your tool on the network from AP Mode.

Open your internet browser and type


"192.168.42.1" into the address bar (this is
always the AP Mode address of your tool).

After pressing enter, your Handibot


Dashboard should appear.



7 FROM AP MODE, we will put your tool on the network. Open the Network Manager (a System App in the left-side panel) to select your Wi-Fi network.



8 Enter the passphrase and then hit Connect ...



The easiest way to identify your Handibot on your network is to use one of the "FabMo Tool Minder" Widgets.




The Tool Minder will provide your tool's IP address for entering into your browser, or you can just click on the green link to go to your Dashboard.



If you don't have a Tool Minder -- maybe because we have not made one for your device yet -- use one of the general methods to identify the IP address of your Handibot.







FAQs and Reminders - NETWORKS (cont)

If your network has an internet connection, you can update FabMo software from the Configuration Manager (System App in left-side panel).



 Once you've identified the IP address for a particular network, it will remain relatively permanent (occasional re-identifications may be needed).